

## INSTRUCTION FOR IRON-ON TRANSFER FOR WHITE/BRIGHT TEXTILES

### WHAT YOU NEED

- a sticker (purchased Bili Camu image printed on a iron-on transfer paper)
- white or bright-colour textile (a T-shirt perhaps)
- a flat, hard and smooth surface to iron on (an ironing board is not recommended due to its softness)
- an iron (no travel iron)

### TRANSFERRING

1 Preheat the iron to the highest setting (takes approx. 5-10 minutes). **Switch off** the steam function! You can also use a transfer heat press. Recommended transfer temperature (for both iron and transfer heat press) is 200°C (392°F) 2 Briefly iron the fabric to ensure that it is completely smooth. 3 Place the transfer film onto the textile with the printed **image facing downwards**. Cover the transfer film with silicone-paper. 4 Iron the transfer film with strong pressure and slow movements.. 5 Don't forget the corners and edges. (The handle duration takes approx. 3 minutes for a A5 sheet)

*Possible brownish discoloration of the white areas of the transfer paper and any arising smells are harmless and will not affect the quality of the transfer in any way.*

**MATT finish:** remove the release paper in a smooth, even movement while it is still hot, starting from one corner.

**GLOSSY finish:** allow the transfer to cool, then peel off the release paper.

### WASHING

- Wash the garment/fabric before wearing/using
- Wait 24 hours before washing for the first time (drying time)
- Wash the textiles with 30-40°C garments inside out. Machine laundry is recommended.
- Do not use aggressive washing detergents or bleach of any kind.
- Do not tumble-dry.
- Iron only on the reverse side.

### ADVICE

For an even more "funky" effect cut out the image, leaving a narrow margin of 1-3 mm around the edge.

**Happy creating!**

[www.bili-camu.com](http://www.bili-camu.com)

